

## DKM-407 DIN RAIL TYPE NETWORK ANALYZER

The DKM-407 is a DIN rail mounted precision unit allowing measurement and monitoring of AC parameters of a distribution panel.

The unit is supplied between L1 and Neutral terminals. Thanks to the supply range of 85-305V, it is not affected by voltage fluctuations and is capable of operating in any network.

The unit features an 32-bit ARM core microcontroller. With a sampling rate of 4096s/s it reaches 0.5% precision.

The isolated RS-485 Modbus RTU port is not affected by ground potential differences.

Program parameters may be uploaded from PC.



### **SAFETY NOTICE**

**Failure to follow below instructions will result in death or serious injury**

- Electrical equipment should be installed only by qualified specialist. No responsibility is assured by the manufacturer or any of its subsidiaries for any consequences resulting from the non-compliance to these instructions.
- Check the unit for cracks and damages due to transportation. Do not install damaged equipment.
- Do not open the unit. There is no serviceable parts inside.
- Fuses of fast type (FF) with a maximum rating of 6A must be connected to phase voltage inputs, in close proximity of the unit.
- Disconnect all power before working on equipment.
- When the unit is connected to the network do not touch terminals.
- Short circuit terminals of unused current transformers.
- Any electrical parameter applied to the device must be in the range specified in the user manual.
- Verify correct terminal connections before applying power.

## INSTALLATION

### **Before installation:**

- Read the user manual carefully, determine the correct connection diagram.
- Install the unit to the DIN rail.
- Make electrical connections with plugs removed from sockets, then place plugs to their sockets.
- Note that the power supply and measuring circuits use common neutral.

### **Below conditions may damage the device:**

- Incorrect connections.
- Incorrect power supply voltage.
- Voltage at measuring terminals beyond specified range.
- Current at measuring terminals beyond specified range.
- Connecting or removing data terminals when the unit is powered-up.
- Overload or short circuit at relay outputs
- Voltage applied to digital inputs over specified range.
- High voltage applied to communication port.

### **Below conditions may cause abnormal operation:**

- Power supply voltage below minimum acceptable level.
- Power supply frequency out of limits
- Phase order of voltage inputs not correct.
- Current transformers not matching related phases.
- Current transformer polarity incorrect.

Detailed user manual of this product  
may be downloaded at:  
[www.datakom.com.tr](http://www.datakom.com.tr)



## ELECTRICAL CONNECTIONS



**Do not install the unit close to high electromagnetic noise emitting devices like contactors, high current busbars, switchmode power supplies and the like.**

Although the unit is protected against electromagnetic disturbance, excessive disturbance can affect the operation, measurement precision and data communication quality.

- **Use cables of appropriate temperature range.**
- **Use adequate cable section, at least 0.75mm<sup>2</sup> (AWG18).**
- **For current transformer inputs, use at least 1.5mm<sup>2</sup> section (AWG15) cable.**
- **The current transformer cable length should not exceed 1.5 meters. If longer cable is used, increase the cable section proportionally.**
- **Follow national rules for electrical installation.**
- **Current transformers must have 5A output.**



**Current Transformers must be used for current measurement.  
No direct connection allowed.**

## TECHNICAL SPECIFICATIONS

**Supply voltage:** 85-305 V AC (L1-NEUTRAL)

**Supply frequency:** 45-65Hz

**Measurement inputs:**

**Voltage:** 10 - 305 V AC (P-N)  
20 - 530 V AC (P-P)

**Current:** 0.2 - 6.00 A AC

**Frequency:** 30 - 100 Hz

**Accuracy:**

**Voltage:** % 0.5 + 1 digit  
**Current:** % 0.5 + 1 digit  
**Frequency:** % 0.5 + 1 digit  
**Power (kW,kVAr):** %1.0 + 2 digit  
**Cos:** %2.0 + 2 digit

**Measurement range:**

**CT range:** 5/5A to 5000/5A  
**VT range:** 0.1/1 to 200.0/1  
**kW range:** 0.1 kW to 6.5 MW

**Power consumption:** < 4 VA

**Loading:**

**Voltage inputs:** < 0.1VA per phase

**Current inputs:** < 1VA per phase

**Relay output:** 5A @ 250V AC

**Digital input:**

**Active level:** 5 - 30V DC or AC

**Min pulse:** 250ms.

**Isolation:** 1000V AC, 1 minute

**Operating temp. range:** -20°C to +70 °C

-4 °F to 158°F

**Max. Relative humidity:** 95% non condensing

**Enclosure:** Flame retardant, ROHS compliant, high temperature ABS/PC (UL94-V0)

**Installation:** DIN rail mounted

**Dimensions:** 70x115x66mm (WxHxD)

**Weight:** 200 g (approximative)

**EU Directives:**

2006/95/EC (LVD)

2004/108/EC (EMC)

**Reference standards:**

EN 61010 (safety)

EN 61326 (EMC)

## PUSHBUTTON FUNCTIONS

Three buttons on the front panel provide access to configuration and measurement screens.

BUTTON	FUNCTION
	<u>Selects display context</u> <ul style="list-style-type: none"> <li>• THD display</li> <li>• Minimum values display</li> <li>• Maximum values display</li> <li>• Demand display</li> </ul>
	<u>HELD PRESSED FOR 5SEC:</u> resets min-max values and displays minimum phase-to-neutral voltages.
	<ul style="list-style-type: none"> <li>• Upper screen</li> <li>• Increase (config.)</li> </ul>
	<ul style="list-style-type: none"> <li>• Lower screen</li> <li>• Decrease (config.)</li> </ul>
	<u>IF NO BUTTON PRESSED FOR 5 MINUTES:</u> returns to the main display screen

## PROGRAM PARAMETERS

SCREEN	FUNCTION
<i>dId</i> <i>CLR</i>	0: No action 1: Reset Demand values
<i>Enr</i> <i>CLR</i>	0: No action 1: Reset kWh and kVArh counters
<i>hU</i> <i>CLR</i>	0: No action 1: Reset hour counter
<i>RLr</i> <i>CLR</i>	0: No action 1: Reset alarms
<i>dSP</i> <i>SEL</i>	Default screen selection (refer user manual)
<i>crt</i>	Current transformer primary (xxx/5A format)
<i>uLT</i> <i>ErF</i>	Voltage transformer ratio (xxx.x/1 format)
<i>uLH</i>	High voltage alarm limit. If set to 0 then does not check high voltage.
<i>uLL</i>	Low voltage alarm limit. If set to 0 then does not check low voltage.
<i>Frq</i> <i>h9H</i>	High frequency alarm limit. If set to 0 then does not check high frequency.
<i>Frq</i> <i>Lo</i>	Low frequency alarm limit. If set to 0 then does not check low frequency.
<i>CrH</i>	Overcurrent alarm limit. If set to 0 then does not check the limit.
<i>ACh</i>	High active power alarm limit. If set to 0 then does not check the limit.
<i>ACl</i>	Low active power alarm limit. If set to 0 then does not check the limit.
<i>rRH</i>	High reactive power alarm limit. If set to 0 then does not check the limit.
<i>rAL</i>	Low reactive power alarm limit. If set to 0 then does not check the limit.
<i>CSH</i>	High power factor alarm limit. If set to 0 then does not check the limit.
<i>CSL</i>	Low power factor alarm limit. If set to 0 then does not check the limit.
<i>nod</i> <i>Adr</i>	Device Modbus address (0-255)
<i>bAU</i> <i>rAt</i>	RS-485 baud rate (0=2400 / 1=4800 / 2=9600 / 3=19200 / 4=38400 / 5=57600 / 6=115200)

## PROGRAMMING

BUTTON	FUNCTION
 	In order to enter the configuration menu, hold both arrow buttons pressed for 2 seconds.
	Pressing the SET button will save the current parameter and display the next parameter.
	Holding the SET button pressed for 2 seconds will display the previous parameter.

## INSTALLATION DIAGRAM

